


USE AND CARE GUIDE

WALL MOUNT FAUCET



Questions, problems, missing parts? Before returning to the store,
call Glacier Bay Customer Service
8 a.m. - 6 p.m., EST, Monday - Friday

1-855-434-5224

HOMEDEPOT.COM

THANK YOU

We appreciate the trust and confidence you have placed in Glacier Bay through the purchase of this faucet. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Glacier Bay!

Table of Contents

Table of Contents	2	Installation	4
Warranty	2	Care and Cleaning	5
Limited Lifetime Warranty	2	Service Parts	5
Pre-Installation	2		
Planning Installation	2		
Tools Required	2		
Package Contents	3		

Warranty

LIMITED LIFETIME WARRANTY

This product has been manufactured under the highest standards of quality and workmanship. The manufacturer warrants to the original consumer purchaser that this faucet will be leak and drip free during normal domestic use for as long as you own it. If this faucet should ever develop a leak or drip during this time, the manufacturer will, free of charge, provide the parts necessary to put the faucet back in good working condition. The manufacturer warrants to the original purchaser that the faucet will be free from defects in material and workmanship for one (1) year from date of purchase. A replacement for any defective part will be supplied free of charge for installation by the consumer. Defects or damage caused by the use of other than genuine parts are not covered by this warranty. This warranty shall be effective from the date of purchase as shown on the purchaser's receipt. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. This warranty is valid for the original consumer purchaser only and excludes industrial, commercial, or business use of the product, product damage due to installation error, product abuse, or product misuse, whether performed by a contractor, service company, or yourself. The manufacturer will not be responsible for labor charges and /or damage incurred in installation, repair or replacement, not for incidental or consequential damages, so the above limitation or exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights which may vary from state, province to province, and nation to nation. The manufacturer will advise you of the procedure to follow in making warranty claims.

Contact the Customer Service Team at 1-855-434-5224 or visit www.HomeDepot.com.

Pre-Installation

PLANNING INSTALLATION

Before you begin to install this product, ensure that all parts are present. Compare parts with the package contents list. If any part is missing or damaged, do not attempt to install the product. Contact customer service for replacement parts.

TOOLS REQUIRED



Adjustable
wrench




Safety
goggles



Sealant
Tape

Pre-Installation (continued)

PACKAGE CONTENTS




Part	Description	Quantity
A	Soap Dish	1
B	Stem	1
C	Spout	1
D	Handle Screw	2
E	Spout Nut	1
F	Handle (hot)	1
G	O-Ring	1
H	Aerator	1
I	O-Ring	1
J	Flange	2
K	Swivel Union	2

Part	Description	Quantity
L	Ceramic Cartridge Assembly (hot)	1
M	Connector	1
N	O-Ring	1
O	Handle (cold)	1
P	Washer	2
Q	Connector	2
R	O-Ring	2
S	Union Nut	2
T	Faucet Body	1
U	Ceramic Cartridge Assembly (cold)	1

Installation


1 Preparing to install the faucet

- Turn off the water at the supply valve under the sink or at the main water supply, disconnect the supply lines, and remove the old faucet.
- Clean and dry the surface area where the new faucet will be mounted.
- Wrap sealant tape (not included) around all the exposed male threaded areas in a clockwise direction.
- Hand-tighten the screw flange (J) onto the swivel union (K) and wrench-tighten the swivel union (K) onto the stub out pipes extending from the wall (do not over tighten).




2 Installing the faucet

- Insert the washers (P) into the union nuts (S), and then wrench-tighten the union nuts (S) to the swivel union (K).




3 Installing the soap dish (optional)

- Hand-tighten the soap dish stern (B) into the top of the nut at the back of the faucet body (T). Place the soap dish (A) on the threaded end of the rod with the edge of the soap dish (A) parallel to the wall.



4 Testing the water supplies

- Open the water supply and check all of the water connections for leaks.
- If you discover any leaks, check the connections to ensure they are installed properly.
- Remove the aerator from the spout, and run the water for approximately 30 seconds to flush the lines.
- Re-attach the aerator.




Care and Cleaning

- Never use harsh abrasives or cleaners with alcohol or acids to clean the faucet.
- To clean, use a soft, damp cloth and warm soap and water and dry with a soft towel.

Service Parts

MODEL TYPE: JY5020181



Part	Description	Part Number
1	Soap Dish	RP326011
2	Stern	RP067004
3	Handle Screw	RP020291
4	Handle (hot)	RP038328H
5	Ceramic Cartridge Assembly (hot)	RP532034NH
6	Flange	RP063334
7	Swivel Union	RP043029N
8	Washer	RP023132N
9	Connector	RP058429N
10	O-Ring	RP027343N
11	Union Nut	RP058428

Part	Description	Part Number
12	Spout Nut	RP058431
13	O-Ring	RP027344N
14	O-Ring	RP027342N
15	O-Ring	RP120345N
16	Connector	RP058430N
17	O-Ring	RP027343N
18	Washer	RP023131N
19	Aerator	RP082018
20	Aerator shell	RP054092B-90
21	Handle (cold)	RP038328C
22	Ceramic Cartridge Assembly (cold)	RP532034NC



Questions, problems, missing parts? Before returning to the store,
call Glacier Bay Customer Service
8 a.m.-6 p.m., EST, Monday-Friday

1-855-434-5224

HOMEDEPOT.COM

Retain this manual for future use.